

Cable Extension Options

Extend the cable run for your camera up to 300ft or more depending on the cable type used. See table below:

Option	Cable Type	Max. Cable Run Distance	Max. # of Extensions
1	Regular BNC (supplied with camera)	180ft / 55m	3
2	'RG59' or 'Coax' or 'Coaxial' BNC (sold separately)	300ft / 92m	5
3	Lorex Universal Cable (sold separately)	300ft / 92m	3

Notes:


1. For optimal performance, consider using option 2 or 3. Preference for using the same cable type for the entire distance.
2. Cable run recommendation based on typical camera power consumption (up to 500mA). For specialty cameras with higher current consumption, maximum cable run may be reduced. Consider providing power to the camera at the camera side rather than at the end of the extension cable.
3. Indicators that your cable run may be too long:
 - Video is permanently Black & White (even during day time)
 - Video is distorted

Troubleshooting

Problem	Solution
No Picture/Signal	<ul style="list-style-type: none"> • Ensure your TV is on the correct input channel. Common terms of an input channel: INPUT, AV CHANNEL, LINE1, LINE2, AUX. • If your camera is connected to a VCR/DVR, ensure it is properly connected to your TV/ Monitor. • Ensure connections are properly connected. • Ensure all the camera power supply is plugged in.
Picture is too bright	<ul style="list-style-type: none"> • Ensure your camera isn't pointed directly at a source of light (e.g sun or spot light). • Slide the sunshade (bullet cameras only) forward to block excess light. • Move your camera to a different location.
Picture is too dark	<ul style="list-style-type: none"> • If using during the day, the camera may not be getting enough light. Slide the sunshade backwards to let in more light. Check the brightness and contrast settings of the device your camera connects to (TV/Monitor/DVR).
Night Vision is not working	<ul style="list-style-type: none"> • The night vision activates when light levels drop. The area may have too much light.
Picture is not clear	<ul style="list-style-type: none"> • Check the camera lens for dirt, dust, spiderwebs. Clean the lens with a soft, clean cloth. • Make sure that the cable run is within the limitations specified in the section 'Cable Extension Options'.
Bright spot in video when viewing camera at night	<ul style="list-style-type: none"> • Night vision reflects when pointing a camera to a window. Move the camera to a different location.
BNC connection does not connect to my TV	<ul style="list-style-type: none"> • Use a BNC to RCA adapter at the end of the extension cable.

Camera Specifications

Image Sensor	1/3" Sony Super HAD™ II
Video Format / Pixels	NTSC: 768(H)×494(V)
Horizontal Resolution	600 TVL
Minimum Illumination	0 LUX (IR LEDs on)
Field of View (diagonal)	39 - 93 Degrees
Lens / Lens Mount	4~9mm F1.6~2.4 / Varifocal
Video Output	Comp. 1.0 Vpp @ 75ohm
Environmental Rating	IP 66
Termination	Video: BNC Female Power: Barrel Female
Operating Temperature	14°F ~ 122°F (-10°C ~ 50°C)
Power Requirement	12V DC ±10%
Power Consumption	500 mA or 6W max
IR / Night Vision Range	35 IR LED/100 ft. (30m)
Weight (with stand)	1.6 lbs. / 0.8 kg



IT'S ALL ON THE WEB!

www.lorextotechnology.com

Product Information	Specification Sheets
User Manuals	Software Upgrades
Quick Start Guides	Firmware Upgrades

Lorex Technologies Inc.
Copyright © 2010 Lorex Technologies Inc.
As our products are subject to continuous improvement, Lorex reserves the right to modify product design, specifications and prices, without notice and without incurring any obligation. E&OE

SUPER RESOLUTION IR VANDAL DOME CAMERA

MODEL: LDC6080 SERIES



QUICK START GUIDE

English Version 1.0

LOREX®

www.lorextotechnology.com

Contents

- 1x Super Resolution Color Camera
- 3 x Mounting screws / 1 x Allen key
- 1x 60ft. BNC/Power Extension Cable
- 1x BNC to RCA Adaptor
- 1x Power Adapter

WARNING - A REGULATED UL/CSA APPROVED power supply is REQUIRED for use with this camera. Use of a non-regulated, non-conforming power supply can damage this product and voids the warranty.

Features

- 600TV line resolution for unmatched video quality
- Latest Sony Super HAD™ 2nd generation Image Sensor
- Advanced Noise Reduction for crystal clear Night Vision
- Improved recording storage efficiency by up to 30%
- Dual glass design prevents IR light reflection
- Varifocal lens for flexible area coverage
- Weatherproof, vandal resistant aluminum housing
- Flexible camera design for wall and ceiling mounting

Installation Tips

- Point the camera where there is the least amount of obstructions (ie tree branches).
- Install the camera in a location that is difficult for vandals to reach.
- Secure cabling so that it is not exposed or easily cut.
- Connect your system and cameras to a back-up power supply. This ensures the system continues to record during power outages.

Warning / Caution Statements

1. Read this guide carefully and keep it for future reference.
2. Follow all instructions for safe use of the product.
3. Use the camera within given temperature, humidity and voltage levels noted in Camera Specifications.
4. Do not disassemble the camera.
5. Do not point the camera directly towards the sun or a source of intense light.
6. Use only the supplied regulated power supply. Use of a non-regulated, non-conforming power supply can damage this product and voids the warranty.
7. The supplied extension cable is rated for surface mounting only. Cables for in-wall / floor-to-floor installations are sold separately.

Installing The Camera

ATTENTION - Test all connections and ensure the camera is working correctly prior to permanent installation by temporarily connecting the camera(s) and cable(s) to the viewing/recording solution.

Before Installing The Camera

- Decide whether to run the cables through the wall/ceiling (drilling required), or along the wall/ceiling.
- If you run the cables along the wall/ceiling, you must run the cables through the opening in the camera base, then tuck the cable into the cable notch on the base. This will keep the camera base flush to the wall/ceiling when mounted.




Cable notch

To install the camera:

1. Remove the three screws located on the outer ring of the Dome Cover using the Allen key (included).



2. Mount the Camera Base to the ceiling or wall using the provided screws.




3. Position the Ball Camera at the desired position and angle.
4. Position the Dome Cover over the Ball Camera. Holding the cover firmly in place, use the Allen key to tighten the screws on the outer ring of the Dome Cover.



Tighten the dome cover using the Allen key.

Connecting The Camera

To Camera:



Male power connector

Female power connector




Connect the BNC and power connectors to the camera.

To Monitor/ DVR:



Connect the BNC connector to the video input of the monitor/DVR, and connect the included power connector to a power adapter.

BNC to RCA Adapter



Attach the included BNC to RCA adapter to connect the extension cable to RCA inputs (i.e. for a TV connection).

Lens Adjustment

Use a screwdriver to adjust the Focus and Zoom control screws on the camera if necessary.



Note: Have a second person verify the camera image when you adjust the Focus and Zoom settings.

Setup Diagram

